

Spindle real replacement (for 8000 rpm)

1. Remove 3 pcs M5 set screws, and replace M5 X 8 cap screws.



2. Use hammer and hit the screwdriver slightly down until there is a gap.



3. Use 2 screwdrivers insert to the gap and force the cover down.



4. Remove the cover down and replace the oil seal.



5. Apply a little oil before install the cover back.



6. Put the cover back up with rubber hammer.



7. Install the set screws.

