

Size of resist for Yasakawa inverter (None ATC)

Inverter	Resistor
2.2 kW / 3 hp	300W-70 OHM
3.7 kW / 5 hp	400W-40 OHM
3.7 kW / 6 hp	600W-40 OHM
5.5 kW / 7.5 hp	600W-30 OHM
7.5 kW / 10 hp	800W-20 OHM

Size of resistor for Fuji inverter

Inverter	Resistor
2.2 kW / 3 hp	300W-70 OHM
3.7 kW / 5 hp	400W-40 OHM
3.7 kW / 6 hp	600W-40 OHM
5.5 kW / 7.5 hp	600W-8 OHM (2X)
7.5 kW / 10 hp	600W-4 OHM (3X)
11 kW / 15 hp	600W-4 OHM (4X)