



1. Go to **Syntec Control**. Select **Maintain**. Then select **User Time Setting** (on bottom right corner).



2. Write down **Serial, CK Sum, Check No.**

Email (atrump@atrump.com) or call (909-623-6887) our office and give us these three information. Then we will assign you an unlocking password.

